

Technical Brief

Aragonite vs Limestone: a comparative technical analysis

Morphology, reactivity, purity and industrial impact of natural oolitic aragonite against conventional calcite limestone.

Summary

Both aragonite and calcite share the chemical formula CaCO_3 , but they are distinct mineral polymorphs. Limestone is composed primarily of calcite — a stable, common, trigonal crystal. AragoCor supplies natural oolitic aragonite, the rarer orthorhombic polymorph, formed as concentrically layered spherical particles in the shallow, warm waters of the Bahamas. The difference in crystal system carries through to solubility, particle morphology and purity — with measurable consequences across glass, agriculture, water treatment, polymer and construction applications.

Side-by-side: aragonite vs calcite

Property	AragoCor Aragonite	Calcite / Limestone	Industrial impact
Crystal system	Orthorhombic	Trigonal (Rhombohedral)	Different lattice → different reactivity
Density (g/cm ³)	2.93	2.71	Higher mass per unit volume
Solubility	Higher	Lower	Faster availability in target systems
Particle morphology	Spherical, oolitic	Angular fragments	Better flow, blending, surface area
Purity (typical)	≥ 97.5% CaCO_3	85–95% CaCO_3	Fewer impurities to manage
Origin	Ocean-renewed	Quarried, finite	Renewable mineral resource
Iron content	Low (≤ 0.04% Fe_2O_3)	Variable	Critical for optical / coatings grades

Why the difference matters

Reactivity

The higher-energy polymorph supports faster CaO availability in glass batches and faster Ca²⁺ availability in agriculture and water treatment systems.

Morphology

Oolitic particles — concentric layered spheres — flow, blend and disperse cleanly in industrial processes.

Purity

Single-origin, low-impurity natural mineral with consistent assay from shipment to shipment.

Ocean renewal

Continuously produced in Bahamian shallows: a natural mineral, regenerated by the planet at scale.

Application considerations

In many systems, aragonite is evaluated as a drop-in or premium alternative to conventional limestone. Because performance is application-specific — dependent on formulation, particle size selection and process conditions — AragoCor recommends a documented trial program before full specification. Our applications engineering team can help design a trial protocol suited to your process and provide a starting grade recommendation.

Conclusion

Natural oolitic aragonite is not a marketing distinction from limestone — it is a different crystal, with measurably different density, solubility, morphology and purity. For specifiers evaluating calcium carbonate inputs on technical merit, that distinction is the starting point for a meaningful trial.

This brief summarizes typical properties of AragoCor natural oolitic aragonite for comparative and educational purposes. Values are representative; request a current certificate of analysis for lot-specific data. © AragoCor Minerals LLC. info@aragocorminerals.com · +1 (855) 751-9100